


Cleaning and Care


CAUTION: Before cleaning appliance, make sure it has cooled down completely (for 30 minutes).



1. Unplug the power cord from the wall outlet.



2. Dispose of grease from the drip tray, once cooled.



To Remove Cooking Plates:

In the flat position, press the plate release buttons on the right of the bottom housing and front center of top housing, then slide the plates out from under the metal brackets.

4. The cooking plates and drip tray can be cleaned in the dishwasher or by hand.



5. The housing base, cover and control can be wiped clean with a soft, dry cloth. The power cord can be wrapped around the back of the base for storing.

IMPORTANT

Do not throw away. Read before operating your new Griddler® Grill and Panini Press.
Keep for future reference.

These helpful hints are intended to be a supplement to the Instruction Booklet. In order to ensure safe operation and optimum performance, please read the entire Instruction Booklet.


QUICK REFERENCE GUIDE

Cuisinart®

Griddler® Grill and Panini Press

Before the First Use

1. Remove all packaging materials and any promotional labels or stickers from your grill. Confirm all parts of your new appliance have been included.



2. Remove any dust from the unit by wiping the base, cover and controls with a damp cloth. Thoroughly clean cooking plates and drip tray (dishwasher safe).

Setup

1. Place the grill on a clean, flat surface where you intend to cook.



2. To Position Drip Tray: Slide the drip tray into the base at the front of the unit.



Setup Instructions Continue Inside

Setup

3.

To Insert Cooking Plates: Adjust to the flat position by pushing the hinge release button. Slide the plate underneath the metal brackets of the housing and push down the front end of the plate. If you require only one plate for cooking, we recommend using the bottom plate.



4.


To Adjust Front Feet

If grilling meats or other food where adequate grease drainage is required, raise the two front feet located at the underside of the grill to engage tilt feature.



5.

Plug the unit into an outlet. The red indicator light will illuminate to indicate the power is on.



6.

Once the unit reaches temperature, the green indicator light will illuminate and you're ready to cook!



Cooking Options

1.

CONTACT GRILL: To cook burgers, boneless meats and vegetables by resting the top cover on top of the food until it has reached the desired cooking temperature.



2.

PANINI PRESS: To grill sandwiches, breads and quesadillas by resting the top cover on top of the food, pressing, and heating to your liking.



3.

FULL GRILL: To cook burgers, steak, poultry, fish and vegetables in the open, flat position.

